



STERI-SPRAY PRO SETUP INSTRUCTIONS

**STERI-SPRAY PRO CONVERTS
WATER INTO AQUEOUS OZONE**

**DISINFECTS STAINLESS STEEL
TANKS AND OAK BARRELS**



Now supplied with a 90 degree stainless steel Jet Spray wand which can be rotated 360 deg. to fully disinfect an entire wine or beer barrel.



INITIAL SETUP

- Remove STERI-SPRAY from the box and attach the stainless steel 90 degree spray wand onto the 2 black wand holders as shown in the above image.
- It's advisable to give the dual batteries an initial charge. Plug-in the charger and it's LED will turn green. Turn on the rocker switch and the charger light will turn red. When the red light turns green the dual batteries will be fully charged and the unit should be turned off before removing the charger's plug. Remember that STERI-SPRAY must always be turned on when the batteries need to be charged.
- Fill the sprayer's tank with about 2 gallons of water to prime the on-demand pump.
- Switch the unit on and the pump will start working. Remove the spray wand and hold down the yellow spray trigger to allow the pump to purge the air out of the system and begin spraying. When you release the trigger the pump will turn off as its internal PSI pressure switch will be activated to provide on-demand spraying.

MOUNTING THE OZONE GENERATOR

- Remove the ozone generator from the accessory box and mount it in front of the sprayer's tank as shown. Firmly tighten the wing nut.
- Locate the short silicon tube and firmly insert one end into the Ozone Generator. The plug is located on the top right hand side of the ozone generator. Remove the blue plastic cover and insert the other end of the silicon tube into the stainless steel fitting on the 5 gallon tank.
- You may mount the ozone generator externally. A longer silicon tube is provided for this application.
- Plug in the ozone generator. Before turning on the ozone generator make sure that the tank is filled with water and that the silicon tube is firmly inserted.

SETTING UP THE OZONE GENERATOR

Check the tank level after having primed the pump. If it's at 1 gallon follow infusion step 1 for 1 gallon. Plug-in the TRI-X3 ozone generator and two zero's will start to flash.

INFUSION SETTINGS – Increase the ozone infusion time for 5 minutes for each gallon of water.

1. FOR 1 GALLON Press the + icon and the ozone generator's timer will go to 5 minutes. Wait 1 to 2 seconds and it will start infusing.
2. For 2 GALLONS Press the + icon 2 times and the ozone generator will go for 10 minutes.
3. For 3 GALLONS Press the + icon 3 times and the ozone generator will go for 15 minutes.
4. For 4 GALLONS Press the + icon 4 times and the ozone generator will go for 20 minutes.
5. For 5 GALLONS Press the + icon 5 times and the ozone generator will go for 25 minutes.

IMPORTANT Aqueous Ozone only lasts for 15 minutes before it reverts to pure water. If the aqueous ozone solution is not used in 15 minutes, the remaining water should be re-infused according to the above schedule.

FEATURES

- The 1 gallon per minute pump has a demand feature which automatically activates the pump when the spray trigger is pressed.
- Equipped with large 8" wheels for unrestricted mobility
- Handle extends to 23 inches.
- Coiled spray tubing extends to 10 ft.
- One year warranty.

UNLEASH THE POWER OF OZONE INFUSED WATER

