



MoreInstructions™

Kegeerator Conversion Kit

Kit Includes:

- 5 lb Empty CO2 Tank
- Dual Gauge Regulator
- Faucet/Knob/Shank Combination
- Stainless Steel Drip Tray
- Sanke Style Tap
- All tubing and hardware



Your CO2 tank is shipped empty - you will have to bring it to a welding shop in your area to get it filled.

Instructions For Use:

- Secure a tall glass of beer as this can be a thirsty job. This will be the last time you have to pour from a can or a glass. Beer on tap is moments away.
- The first step is to decide where you want the faucet to be on the outside of the refrigerator. Mark the spot and then drill a 1" hole. You will need a 1" hole saw bit and a very sturdy drill. This is the only hard part of the installation.
 - Take the back nut off of the threaded shank and push the shank into the hole you just drilled, so that the flange (usually black) is flush with the outside of the refrigerator. Screw the back nut onto the back of the shank, from inside the refrigerator, so that the shank is firmly secured.
 - Connect your dual gauge regulator to the 5 lb CO2 tank with a crescent wrench. Do not overtighten the regulator as you may split the built-in gasket if too much force is applied. The gauge that goes to 2000 psi is your tank gauge and tells you how much gas is left in your tank. A normal 5 lb CO2 tank will hold from 600-1000 psi of pressure when filled, depending on the temperature the tank is stored in. The gauge that goes to 60 psi is your outgoing gauge and tells you what amount of pressure is being released into the keg.
 - The tap comes with the CO2 line attached to reduce confusion. Using the screw clamp that is already on the gas line, attach the gas line to the barbed outlet on the the regulator.
 - The beer line and hex nut that is currently hanging from the bottom of the regulator threads onto the top of the tap. Be sure to utilize the rubber gasket that was included in the tower box.
 - After everything is connected you will need to open the valve on the top of the CO2 tank. Open the black valve on the outlet of the regulator by turning the valve to the vertical position. If you hear any leaking shut it off and inspect the gas line clamps and fitting on the regulator and tap.

If you do not hear any leaks then you can adjust the pressure on the regulator. Usually 8-12 psi is best, but different beers will have different requirements. You can increase the outgoing pressure by screwing in the adjustment screw on the regulator body. By loosening the screw you decrease the pressure.

- 7) Attach the CO2 line to the dual gauge CO2 regulator. Attach the beer line to the nipple on the back of the shank (the same shank you previously installed through the refrigerator.)
- 8) With the pressure on, we are ready to tap the keg . Place the tap on top of the keg and twist the entire tap body clockwise. Then twist the black handle clockwise. Your beer is tapped. Run, don't walk, to the nearest pint glass and test the system out.

After note: Your sanke tap is the choice for about 90% of the keg beers on the market. If you decide to tap a European, German, or English keg you will most likely need to purchase the corresponding tap.